

別紙 1

No.	型式名称 (正)	本体又は添付書に 表示していた型式名称 (誤)
1	TS.No.DR28SC2	DR28SC2
2	TS.No.DR30C2	DR30C2
3	TS.No.DR77R2	DR77R2
4	TS.No.DR28C2	DR28C2
5	TS.No.DR76U2	DR76U2
6	TS.No.GM175D	GM175D
7	TS.No.GM70J	GM70J
8	TS.No.CA-5011	CA-5011
9	TS.No.CA-502	CA-502
10	TS.No.CA-51	CA-51
11	TS.No.CA-604AM	CA-604AM
12	TS.No.CA-604HG	CA-604HG
13	TS.No.CA-606/OV	CA-606/OV
14	TS.No.CA-705/HG	CA-705/HG
15	TS.No.CA-707/HG	CA-707/HG
16	TS.No.CA-710/OV/AG	CA-710/OV/AG
17	TS.No.CA-715/OV	CA-715/OV